

Cobb DTC Codes (Extended)

1. Cobb 1
 - a. Below minimum voltage range 0.25V
2. Cobb 2
 - a. Above maximum voltage range 4.75V
3. Cobb 3
 - a. Low Voltage Input TGV (Right, Fuel Pressure)
4. Cobb 4
 - a. High Voltage Input TGV (Right, Fuel Pressure)
5. Cobb 5
 - a. Maximum Safe Ethanol Concentration Exceeded
6. Cobb 6
 - a. No Power, Module Not Plugged in
 - i. Usually accompanied by P2016 and 2021
7. Cobb 7
 - a. Loss Communications
 - i. Usually accompanied by P2016 and 2021
8. Cobb 8
 - a. Gateway Module Not Detected
9. Cobb 9
 - a. Lost communications with Gateway module
10. Cobb A
 - a. Gateway firmware is the incorrect version.
11. Cobb B
 - a. CAN Gateway General Packet Error
12. Cobb C
 - a. Gateway Custom Sensor Error
13. Cobb D
 - a. Gateway Inconsistent Sensor
14. Cobb E
 - a. Gateway Ethanol Sensor Error